## Specifications USB Mini Hand Fan GO-F02

Product name / Brand	LINUO
Type / Model	GO-F02
ArtNo. white	GO-F02W
ArtNo. Blue	GO-F02B
ArtNo. pink	GO-F02P
ArtNo. dark	GO-F02D
ArtNo full white	GO-F02FW
ArtNo. full dark blue	GO-F02FD
ArtNo. full green	GO-F02FG
Product image / colors	
Product	USB rechargeable Mini Hand Fan with holder/stand removable, rotatable (90°), extendable
Use	ideal for office, home, workplace, outdoor, travel, camping, caravan, also suitable for menopausal women
Speed level	3 speed level (low, middle, high)
Lenght of use	low, approx. 6,5 hours
	middle, approx. 3,5 hours
	high, approx. 2 hours
Charging time	2,5 hours
Housing	robust housing with protective grille, standing/mobile phone holder (removable, 90° rotatable and extendable), silicone mat on base
Operation	Built-in rechargeable Lithium Battery, can also be used with the included USB cable
Battery	2000mAh (18650), Lithium Built-in Battery
Battery Voltage	3.7V
Input	DC5V-0.8mA
Charging current	1A
Working current	0.4A - 1.4A
Power	low level: 1.3W middle level: 2.6W high level: 3.5W
Charging	rechargeable with included USB charging cable via USB interface with any PC, Notebook, Powerbank or USB 2A adapter
Material	ABS / PP / Electronic components
Motor speed	1570rpm (Low) 2050rpm (Middle) 2450rpm (High)
Delivery	USB Mini Hand Fan GO-F02 USB charging cable, 1m Manual
Dimensions	182,5 x 95 x 37,2 mm
Dimensions Packaging Single Box	230 x 105 x 40 mm
Weight	163 gr
Weight incl. Packaging	238 gr
Cable length	1 meter
Master carton	80 pieces
Dimensions/Weight Master carton Manual	54,3 x 47,7 x 34,3 cm / N.W. 18,4 kg / G.W. 19,5 kg English, Chinese (Manual in packaging) / German, English (Spezifications online)
Warranty	1 year
EAN Code GO-F02W	7640117141031
EAN Code GO-F02B	7640117141048
EAN Code GO-F02P	7640117141055
EAN Code GO-F02D	7640117141062
EAN Code GO-F02FW	7640117142458
EAN Code GO-F02FD	7640117142441
EAN Code GO-F02FG	7640117142465

HTS Code	8414.51.91.00
Classification / Standards	CE, RoHS, FCC
Origin	Made in China
Product maintenance	Please charging for more than 2 hours after purchasing fan, if don't need to use fan. Please charging it every 3 months to avoid damage to the battery.
Main function	The fan has 3 operating levels. When the button is pressed for the first time, the low operating level is set. Click the button for the middle operating level again and the third click on the button sets the highest operating level. The fourth click on the button turns off the fan. If the battery is low, the charging indicator flashes red quickly until the battery is empty. As soon as the battery is empty, the red light goes out.
Notice	Children in 0-10 years old should not use this product alone. To ensure fan power, please use 2A adapter and USB data cable. Do not put product into or near fire in order to avoid fire and explosion hazard.

## Telephone holder / stand

removable, rotatable and extendable, can also be used as a stand

**1.** Stretch the holder and fix your phone.

**2.** The holder can be rotated 90 degrees for better using.

