物料明细		
名称: 小天使加湿器说明书	物料编码: 4.05.02.02.25.001	
材质: 128g 哑粉纸	印刷:双面专色印刷	
表面: /	工艺: 风琴折	
备注:		
制作: 黄路宏	TEL: 13640931501	

展开尺寸: 131*375mm







关规定,规范我司售后制度。现对您所享受的保修权益作以下说明: 1)购买下单时,请留下您的真实信息,如因联系方式不准确导致本公

2)若在正常使用情况下,由于产品本身质量问题引起的故障,在保修期内,我司将承担免费的维修服务。自购买本产品之日起,享有一年

· 因使用不当或缺乏合理的保养造成的产品损坏(如使用错误的电流

・因火灾、地震、水灾、雷击、其他自然灾害、公害或电源、电压异

司无法实际履行免费保修的服务义务,购买者自行承担责任。

电压,将产品插入不合格的插座,其他人为破坏等)。

3)下列情况不属于保修范围:

故障问题 排除问题 检修方法 电源是否接通? 重新插好电源插头,打 电源开关是否打开? 开电源开关。 设备不工作 是否选用了匹配的电源 确认电源适配器的规格 适配器? 水箱内是否装水? 加入适量的水。 水量是否足够接触到吸 棉棒在使用前是否用水棉棒在清水中浸润。 不喷雾或 喷雾量小 浸润? 吸水棉棒是否污染或老 更换吸水棉,清洗机 身下部的吸水孔。 化严重? 使用了不利于机器工作 的水质? 1.关掉电源,拔掉电源线; 机头意外 2.旋开机头,拔出吸水棉; 3.轻甩机头内部积水,置于安全位置24小时自然 进水

· 在保修期内、对于因材料或生产引起的各种瑕疵,公司予以更换零

件或产品。申请保修时请务必将瑕疵产品以及能够证明购买日期的单

常等造成的产品故障或损坏.

4)保修期内终止保修的情况:

· 产品使用非本公司的零件。

产品经非本公司授权人员的修理或拆装。

据(购买发票)一并送至本公司授权的客服中心。 6)在保修期内所替换的零件或整机为本公司所有。







water, oily liquid such as perfume and essence. Otherwise it can lead to condensation or blockage at the spray orifice.


Thank you for choosing our original product—HUMIDIFIER. In order to use our products in an effective way, please read this manual carefully

The machine makes mist by atomizer plate to humidify the air. Please keep the instruction for future reference. If you encounter any problems in the use components, please contact us, we will serve you wholeheartedly. Thank you for your cooperation!

Product name: Angle humidifier Operating voltage: DC 5V= Max power: 2.5W Timing shutdown: 4 hours Dimension: 67*95*176mm Material: ABS+PC Tank capacity: 230mL Volume of spray: 40mL/h(±10)


Product net weight: 175g Implementation standards: GB47061-2005 / GB4706,48-2009 Place of Origin: Shenzhen, China

Humidifier 1 pc, USB cable 1 pc, Cotton stick 1 pc, Manual 1 pc.



2Add proper water to the tank, don't exceed the maximun lever.tighten the upper cover:

(2) Directions for use



(3)Replace cotton swab ①Pull out the cotton stick; ②Replace the cotton stick.



water shortage. 2)Please fill with natural mineral water . Do not add purified water . distilled water , oily liquid such as perfume and essence , or it will cause

condensation or blockage of spray orifice. 3) This product is equipped with automatic power off function . When the $\,$ stated spray time is over , the product will automatically stop spraying . If $\hfill \hfill$ you need to continue to use, please observe the water in the tank first.

Press the function button to start again. 4) When cleaning products, please do not directly wash With tap, avoid short circuit, commended to use soft cloth to wipe . Do not use organic

solvents such as gasoline / alcohol. 5) This product is not suitable for children under 10 years old individually

absorption hole.

 Turn it off and take out the power cord. 2.Get it out of the water cup and open it, take out the cotton and put it into a dry and ventilated place. Please use soft brush to clean the water

consumers to use quality products of our company, we will strictly abide by the relevant laws issued by the state and comply with the specific provisions of China consumer rights and interests protection law and China product quality law. Here is a description of your warranty rights: 1)Please leave your true information when placing the order, If the company cannot actually perform the service obligation of free warranty due to the inaccurate contact information, the buyer shall bear the

2)In case of failure caused by product quality problems under normal use, our company will undertake the maintenance service for free within the warranty period. From the date of purchase of this product, enjoy one year of free warranty service.

3)The following situations are not covered by warranty: Caused by improper use or lack of reasonable maintenance of product damage(such as using the wrong current voltage, insert the

products unqualified socket, other man-made destruction, etc. • Due to fire, earthquake, flood, lightning and other natural disasters, public nuisance or power supply, such as abnormal voltage caused by the product failure or damage.

4)Termination of the warranty period:

• Products are not authorized by the company to repair or disassemble

 Product use non-company components. During the warranty period, the company will replace the parts or products for various defects caused by materials or production. When applying for the warranty, please be sure to send the defective

product together with the purchase date(purchase invoice) to the customer service center authorized by the company. 5)The replacement parts or complete machines within the warranty period are owned by the company.

Failure problems	Troubleshooting	Solution
Decive no working	Check if the power is turned on, and the power switch is on.	Re-plug the power plug and turn on the power.
	Check if use the right standard adaptor.	Confirm the specification of the adaptor.
No spray or small spray Whether the absort cotton is contamina or aged seriously of the liquid which ma	Make sure the water is filled with water or the water is full enough to contact with the cotton.	Fill the cup with suitable water.
	Cotton swab is dipped in water for a while beforeswitch on.	Dipped cotton swab in water for several minutes before using.
	Whether the absorbent cotton is contaminated or aged seriously or used the liquid which may damage the machine.	Replace the absorbent cottonand clean the abosorption hole of the body's botton part under the circumstances
Pour water on hand piece by accident	1.Turn it off and pull out the USB charging cable. 2.Open the hand piece and take out the cotton. 3.Gently shake the machine head and leave it in a safe position for 24 hours to air dry naturally.	

反面