Snow Mountain Hum idifier Instruction

Product Parameters

Product name: Snow Mountain Humidifier

Model: GXZ-J623

Material: ABS/PP/PC/Silicone/Hardware/Electronic parts

Input Voltage: DC5. 0V


Working Current: 200-450mA Using power: 1. 0-2. 25W Water capacity: 500mL Spray amount: 30mL-50mL/H

Product size: 95*95*129mm Product Weight: 236a

Quality inspection: Qualified product

Executive standard: GB 4706.1-2005 GB 4706.48-2009

Original: China Shenzhen



Spray Nozzle



Operating Instructions

Spray button: 1st single press mist button to start the continuous mist mode.2nd single press mist button to start the intermittent mist mode(spray 3s and stop 2s).3rd single press mist button to turn off all mist modes.

Night lamp function: Long press the mist button 1st time,the LED light will be on(warm light),long press the mist button 2nd time,the LED light will be on(breathing light),long press the mist button 3rd time, the LED light will be off.

USB charging port: Input 5.0V to charge humidifier by USB port.

Lack of water protection. When the water level is lower than the stylus pin, it will stop working.

Indicator LED function

Charging indicator: The red light on when input 5.0V charging.

Lack of water indicator: When the water level is lower than the stylus pin, red light flashes three times then off working.

Operating Steps



Open upper cover counter clockwisely



Add water in the water tank



Tighten the cover Clockwisely and connect to USB



start humidifier

Cotton filter replacement



Pull out the cotton filter for replacement



Please pay attention to the bottom spring when replacing

Cautions

- Please add water before using this product. Humidifying function is prohibited in case of water shortage.
- This product can not add any essential oil or perfume to avoid oily clogging of the transducer.
- This product is designed with wate-lacking protection. When lack water the humidifier will automatically stop mist spray.
- To continue working, please add water to the maximum water leve of water tank and press the button restarting.
- Please do not apply water on the machine directly, in case of short-circuit of the machine, to use soft cotton to wipe.
 Children under the age of 6 should be accompanied by adults to use the machine.